


SINUMERIK 840D/810D/FM-NC

Short Guide
Operation

12.98 Edition

User Documentation

Overview of SINUMERIK 840D/810D/FM-NC Documentation (12.98)



*) These documents are a minimum requirement for the control

SINUMERIK 840D/810D/FM-NC

Short Guide Operation

Valid for

<i>Control</i>	<i>Software version</i>	
SINUMERIK 840D		5
SINUMERIK 840DE (Export version)		5
SINUMERIK 810D		3
SINUMERIK 810DE (Export version)		3
SINUMERIK FM-NC		3

12.98 Edition

SINUMERIK® documentation

Printing history

Brief details of this edition and previous editions are listed below.

The status of each edition is shown by the code in the "Remarks" column.

Status code in the "Remarks" column:

A New documentation

B Unrevised reprint with new Order No.

C Revised edition with new status.

If factual changes have been made on the page since the last edition, this is indicated by a new edition coding in the header on that page.

Edition	Order No.	Remarks
11.94	6FC5298-0AA10-0BP0	A
04.95	6FC5298-2AA10-0BP0	C
03.96	6FC5298-3AA10-0BP0	C
08.97	6FC5298-4AA10-0BP0	C
12.98	6FC5298-5AA10-0BP0	C

This manual is included in the documentation on CD-ROM (**DOCONCD**)

Edition	Order No.	Remarks
02.99	6FC5298-5CA00-0BG0	C

Further information is available on the Internet under:
<http://www.ad.siemens.de/sinumerik>

This publication was produced with WinWord V 7.0 and Designer V 4.0.

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility model or design, are reserved.

Other functions not described in this documentation might be executable in the control. This does not, however, represent an obligation to supply such functions with a new control or when servicing.

Subject to change without prior notice.

© Siemens AG 1994 - 1998 All Rights Reserved.

Introduction



MMC 100.2 MMC 103

Validity

Unless stated otherwise, this operator's guide applies to the SINUMERIK 840D/810D and SINUMERIK FM-NC controls

How to use this booklet

This booklet is an operator's guide describing all the main programming steps.

The aim is to provide the operator with some quick help and a memory aid especially for commands that are used infrequently or to offer a quick reference on various parameters.

This guide therefore has little text!

First familiarize yourself with the symbols below so that you understand them better whenever they occur on the following pages.


The symbols



Gives you a tip or background information



Screen displays



Operation via softkeys



Input through the operator keyboard



Input through the machine control panel


List of Sections

Operator Control	1
Set-up	2
Manually Controlled Operation	3
Part Programming	4
Program Management	5
Automatic Mode	6
Alarms and Messages	7


1. Operator Control

1.1 Key assignments slimline operator panel OP 031	1-10
1.2 Key assignments slimline operator panel OP 032	1-11
1.3 Key assignments operator panel	1-12
1.4 Key assignments external machine control panel	1-13
1.5 Graphical user interface	1-16
1.6 Operating areas	1-18
1.7 Operating principle	1-19

1.1 Key assignments slimline operator panel OP 031





MMC 100.2 MMC 103




- 1 Machine area key
- 2 Recall
- 3 Softkey bar (horizontal)
- 4 ETC key (menu extension)
- 5 Area changeover key
- 6 Softkey bar (vertical)
- 7 Alphanumeric key
- 8 Correction/cursor block with control keypad and Input key

1.2 Key assignments slimline operator panel OP 032



- 1 Machine area key
- 2 Recall
- 3 Softkey bar (horizontal)
- 4 ETC key (menu extension)
- 5 Area changeover key
- 6 Softkey bar (vertical)
- 7 Alphablock
- 8 Correction/cursor block with control keypad and Input key
- 9 Numeric block
- 10 Slot for PCMCIA adapter

1.3 Key assignments operator panel



Meaning of the key symbols:

The keys marked with * correspond to the US layout.



		Switch over channel
		Acknowledge alarm
		Information
		Select window
		Move cursor
		Page up
		Delete character
		Blank
		Selection key/toggle key
		Edit/Undo
		Shift
		End of line
		Page down
		Input (accept)




For keys with double assignments:

		Shift with key "Shift"
--	--	------------------------

1.4 Key assignments external machine control panel



Machine control panel for turning machines



Machine control panel for milling machines



The keys marked with * correspond to the US layout.

1 Emergency stop pushbutton

2 Mode and machine functions



Jog

MDA

Automatic

Teach In

1.4 Key assignments external machine control panel





























MMC
100.2



MMC
103



		 REPOS *	Repos
		 REF POINT *	Ref
3	Incremental travel		
4	Program control		
		 RESET *	Reset
		 SINGLE BLOCK *	Single block
		 STOP *	NC Stop
		 START *	NC Start
5	Axis keys for turning machines		
			Axis keys (with direction)
		 RAPID *	Rapid traverse override
		 WCS MCS *	MCS/WCS
	Axis keys for milling machines		
			Axis keys
			Direction keys
		 RAPID *	Rapid traverse override
		 WCS MCS *	MCS/WCS

1.4 Key assignments external machine control panel




MMC
100.2



MMC
103

6 Spindle control



Spindle override




Spindle stop



Spindle start

7 Feed control



Feed/rapid traverse override




Feed stop



Feed start

8 Keyswitch

1.5 Graphical user interface



MCS Position

	Repos offset
+ X 900.000 mm	0.000
- Y -156.000 mm	0.000
+ Z 230.000 mm	0.000

Auxiliary functions

M0	
M0	
M0	
M0	
M0	
H0.000000	
H0.000000	
H0.000000	

Feedrate mm/min

Actual	3000.00	0.0%
Set	3000.00	

Tool

Preselected tool: [arrow] [11]

G0 [arrow] G91

Bottom bar: Machine (16), Parameter (12), Program (14), Services, Diagnosis, [17] [10]



- 1 Operating area
- 2 Channel status
- 3 Program status
- 4 Channel and mode group
- 5 Alarm and message line

1.5 Graphical user interface



MMC
100.2




MMC
103




- 6 Mode
- 7 Program name
- 8 Channel operational messages
- 9 Channel status display
- 10 Information relating to the menu bar
- 11 Work windows and NC displays
- 12 Dialog line with notes for operator
- 13 Focus
- 14 Horizontal softkey bar
- 15 Vertical softkey bar
- 16 Recall
- 17 etc.

1.6 Operating areas



The standard functions in the control are organized into the following operating areas:



When you press the "Area changeover" key, the operating areas in the main menu appear in the horizontal softkey bar. You can use this key to switch from any menu to the main menu.

1.7 Operating principle



MMC 100.2 MMC 103


The MMC 100.2 and MMC 103 provide a range of key and softkey assignments which have the same function in all operating areas and menus.



Area changeover:



Switch back from any menu to the main menu of your control.



Softkeys:



Horizontal softkeys:

These keys subdivide each operating area into further menu levels. Each horizontal menu item has a vertical menu bar/softkey assignment.



Vertical softkeys:

Assigned with functions for the currently selected horizontal softkeys.

1.7 Operating principle



MMC 100.2 MMC 103



Navigation in the menu window:



Change menu windows:

Change the focus to the selected menu window.



Scroll in the menu window:

Scroll one screen page down or up.



Position cursor in the menu window:

Position the cursor at the desired point in the menu window.

1.7 Operating principle



MMC 100.2 MMC 103



Navigation in the directory tree:



Select directory/file:

Position the cursor on the desired directory/file.



Open/close directory:

Open or close the selected directory.



Open file:

Open the desired file, e.g. if you want to edit the file in the ASCII editor (in this case the editor is opened automatically).



Select file (MMC103):

Select the desired file.




Select several files (MMC103):

Hold down the "Shift" and "Cursor Down" keys.



Select start of block.



Neighboring files are selected when you hold down the "Cursor Up" or "Cursor Down" keys.



Deselect selected files.



Cancel all selections.

1.7 Operating principle



MMC 100.2 MMC 103



Edit inputs/values:

If you want to edit inputs/values, the corresponding key is always displayed automatically on the right of the input field. The following input fields are available:



1. **Option fields** (radio buttons or check boxes):
Activate or deactivate the option field.



2. **Input fields:**
Switch to input mode.

Enter the value or word (e.g. file name, type, etc.) on the numeric keypad.



You automatically switch to input mode if you first position the cursor on the input field.



Always confirm your input with the "Input" key. The value is accepted.

1.7 Operating principle



MMC 100.2 MMC 103



You can use the "Toggle" key to select one of several default values.

3. Selection list (MMC 103):
Display the preselection of possible values.



Open selection list



Position the cursor on the desired values.



Always confirm your input with the "Input" key. The value is accepted.



Switch to the next value in the selection list without displaying the entire list.

1.7 Operating principle



MMC 100.2 MMC 103



Confirm/cancel input:

OK

Confirm input:

Save the inputs and exit the current menu (you automatically return to the calling menu).

Cancel

Cancel input:

Reject the inputs and quit the current menu (you automatically return to the calling menu).



Reject the inputs and quit the current menu (you automatically move up one level).



Clear the current input but remain in the current menu.

1.7 Operating principle



MMC 100.2 MMC 103

Operation with the mouse:

If you have installed a mouse, operation is facilitated as follows:

1 "click"

1 click means:

- Activate the menu window.
- Position the cursor on the desired input field.
- Select directory.
- Activate softkey.
- Activate/deactivate radio button/check box.
- Activate input field.
- Open selection list.

2 "clicks"


2 clicks mean:

- Accept value/input.
- Open directory.

2. Set-up



2.1 Approach reference point	2-28
2.2 Enter tool offsets	2-29
2.3 Calculate tool offsets	2-30
2.4 Enter/alter zero offset (MMC100.2)	2-31
2.5 Enter/alter zero offset (MMC103)	2-32
2.6 Scratching method/determine zero offset (MMC100.2)	2-34
2.7 Scratching method/determine zero offset (MMC103)	2-35
2.8 Program the setting data	2-36

2.1 Approach reference point



Caution:

Position the axes if they are not already located at a safe position.
Always follow the axis movements directly on the machine. Ignore the actual value display as long as the axes are not referenced (the software limit switches are not effective).



Select "Machine" operating area.



or



Choose "Jog" or "MDA".



Select "Ref" machine function.



Turning machine:
Traverse axes.



Milling machine:
Select axes and





traverse axes.



Stop axis before reference point is reached.

2.2 Enter tool offsets




Parameter

Select "Parameter" operating area.

Tool offset

Select "Tool offset" menu.



T no.
+

Choose the desired function:

Select tool (T no.).

T no.
-

D no.
+

Select tool edge (D no.).

D no.
-

Delete

– Delete tool/tool edge

Go to

– Find tool

Overview...

List existing tools.

New...

Create new tool/tool edge.




Enter the new values.

2.3 Calculate tool offsets



MMC 100.2 MMC 103



Parameter


Select "Parameter" operating area.

Tool offset

Select "Tool offset" menu.



Position cursor on desired tool parameter.



Determine compensa.

Select axis and enter reference value.


Calculate

The current position and the reference value of the selected tool parameter are calculated automatically.

2.4 Enter/alter zero offset (MMC100.2)



MMC
100.2



Parameter

Select "Parameter" operating area.

Zero offsets

Select "Zero offsets" menu.


Overview

Select zero offsets:

- settable
- active settable
- active programmable
- sum of active ones
- external ones
- basic offsets



Position the cursor on the desired field and enter/alter the value, or use the "Toggle" key to choose a new value.




Save

Save the values.

2.5 Enter/alter zero offset (MMC103)



MMC
103



Parameter

Select "Parameter" operating area.

Zero offset

Select "Overview of settable zero offsets" menu.



Axes +


Select zero offset:
Changes to the defined zero offsets of the next or previous axis.

Axes -

Offsets

Rotation,
scal., mirr.

Change display mode of the currently displayed zero offset. The display shows either the absolute offsets or the proportional values of rotation, scaling or mirroring.



Basic ZOs

Enter/change zero offset:

Display all the defined basic zero offsets.

Sett. ZOs

Display all the defined settable zero offsets.

2.5 Enter/alter zero offset (MMC103)



MMC
103



Position the cursor on the desired field and enter/alter the value.




Please note:

Changes in the zero offset are updated at entry.

2.6 Scratching method/determine zero offset (MMC100.2)



MMC
100.2



Parameter



Zero
offsets

Determine
ZO



OK

Select "Parameter" operating area.

Select "Jog" mode.

Select "Zero offsets" menu.

"Determine ZO (scratching)" window, enter

- the tool (T no.),
- the tool edge (D no.),
- the corresponding length parameters (1, 2, 3) and the direction (+, -, none),
- the allowance and direction of the radius (+, -, none),
- the allowance and direction of a user-definable offset (+, -, none).

You can select values using the "Toggle" key.


Traverse axes (scratching).

With "OK" all the values are entered into the selected zero offset.

2.7 Scratching method/determine zero offset (MMC103)



MMC
103



Machine

Select "Machine" operating area.

Scratching

Active level, active zero offset and active tool are selected.



Select axis which shall be traversed, with the cursor.



Traverse axis to the workpiece, enter desired set position and confirm with "Input". The offset is calculated.



OK

With "OK" all the values are entered into the selected zero offset.





Please note:

The calculation of the offset always refers to the current workpiece coordinate system (WCS).



In order to take account of the tool geometry, position the cursor in the column "Geometry + wear" on the axis which shall be traversed and select with "Toggle" key, how the tool offset shall be calculated.

2.8 Program the setting data




Parameter

Select "Parameter" operating area.

Setting data

Select the "Setting data" menu.



Work area limit.

Define operating states using setting data:

- Change working area limitation.

Jog data

- Change jog data.

Spindle data

- Change spindle data.

Feedrate DRY

- Change dry run feedrate for DRY test mode.

Starting angle

- Change starting angle for thread cutting.

Misc.

- Display miscellaneous setting data.

Protection zones

- Choose level for protection zone.

2.8 Program the setting data



MMC 100.2 MMC 103



Position the cursor on the desired field and change the value, or





select a new value using the "Toggle" key.

3. Manually Controlled Operation

3.1 Jog/Jog-Inc mode	3-40
3.2 MDA mode	3-42
3.3 Teach In mode	3-43

3.1 Jog/Jog-Inc mode



Machine

Select "Machine" operating area.

Jog

Select "Jog" mode.



"Reference point approach" is deactivated.



Turning machine:
Traverse axes.




Milling machine:
Select axis and



traverse.



The traversing velocity is stored in the "setting data".




If necessary, use the override to set the velocity.




If necessary, move axes with rapid traverse.

3.1 Jog/Jog-Inc mode



Select/enter increment value for traversing position ("Inc"):

Traverse axes in defined increments, or





Inc

enter the desired increment.



Traverse axis with the entered increment.

3.2 MDA mode



Machine

Select "Machine" operating area.

MDA

Select "MDA" mode.



In "Teach In" mode, it is only possible to insert blocks at points in the program which have not yet been executed.



Enter NC block (one or several consecutive program blocks).



Confirm input.



Execute NC block.




MDA-Prog.
sichern

Save program in MDA buffer.



If no program name is entered, the program is automatically stored in the MDA buffer with the name OSTORE.MPF (MMC100.2) or MDAX.MPF (MMC103).

3.3 Teach In mode



Machine

Select "Machine" operating area.

MDA

Select "MDA" mode.



Select "Teach In" submode.



In "Teach In" mode, it is only possible to insert blocks at points in the program which have not yet been executed.



1. Manual positioning:



Turning machine:
Traverse axes.



Milling machine:
Select axis and




traverse.




The axis name and the traversed path are displayed in the "Teach In program" window.

3.3 Teach In mode



2. Manual input of coordinates:

- Enter coordinates of traversing positions and
- enter additional functions (preparatory conditions, miscellaneous functions, etc.) in the "MDA program" window.



MMC100.2

Delete the current block.

Delete block

Insert an empty line before the current block.


Insert block

Save new axis positions and additional functions.

Save block



Executed the entered program blocks and display them in the current block window.





MMC103

Enter and delete blocks on keyboard. Positions are automatically saved at entry.

4. Part Programming


4.1 Select/enable workpiece/part program	4-46
4.2 Open/edit part program	4-47
4.3 Create new workpiece/part program	4-49
4.4 Execute workpiece/part program	4-50
4.5 Copy/paste, rename, delete, enable	4-51
4.6 Load/unload program (MMC 103)	4-53

4.1 Select/enable workpiece/part program



Program

Select "Program" operating area.



Select workpiece/part program:

Work-pieces

Select the level:

- Workpieces

Part programs

- Part programs

Sub-routines

- Subroutines

Standard cycles

- Standard cycles (MMC100.2)

User cycles

- User cycles

Clipboard

- Clipboard




Position the cursor on the desired file in the directory tree.

4.2 Open/edit part program



MMC 100.2 MMC 103



Program

Select "Program" operating area.



Open part program:


Position the cursor on the desired file in the directory tree.



Open program in ASCII editor:



Press the "Input" key.




Interactive
progr.

Activate interactive programming (MMC103):

Press softkey "Interactive progr.".

4.2 Open/edit part program

MMC
100.2MMC
103

Overwrite

Edit part program:

Toggle between insert and overwrite mode.

Mark
block

Mark the beginning of block.

Copy
block

Save the block in the Clipboard.

Delete
block

Delete block.

Insert
block

Paste the block from the Clipboard.

Search/
go to ...

Position on block no., beginning of file, end of file or search string.

Search

Enter search string.

Substitute

Enter substitute.

Continue
search

Next occurrence of search string.

Go to ...

Enter block no.


Save
file

Save part program.


Close
editor

Close text editor.

4.3 Create new workpiece/part program




MMC 100.2 MMC 103



Program

Select "Program" operating area.



Workpieces

Part programs

Sub-routines

Select "Workpieces", "Part programs" or "Subroutines".

Open directory.

New ...

Enter name of workpiece, main program or subroutine and



select "File type".





MMC103:

Select key


- text editor
- activate interactive programming.

4.4 Execute workpiece/part program



Program

Select "Program" operating area.



Work-
pieces

Select workpiece:

Mark the desired workpiece with the cursor in the workpiece overview.

Selection

Select the workpiece.

Part
programs

Select part program:

Mark the desired workpiece with the cursor in the part program overview.

Selection

Select the part program.





Start the workpiece/part program.



Clip-
board

You can also run part programs directly from the Clipboard.

4.5 Copy/paste, rename, delete, enable



Program


Select "Program" operating area.



Select the level and position the cursor on the desired file in the directory tree.

Manage programs

MMC103:
Select "Manage programs".



Copy

Copy/paste program:


Select the source file.

Paste

Save the source file in the target directory.



If necessary, use the "Toggle" key to select the file type.



Rename

Rename the program:

Press the "Rename" softkey and enter new name.




Use the "Toggle" key to select the file type.

4.5 Copy/paste, rename, delete, enable




MMC 100.2 MMC 103



Delete program:

Delete the program from the directory.

Delete



Change enable:


Set (x) or cancel () enable.

Change enable

4.6 Load/unload program (MMC 103)



MMC
103




Program

Select "Program" operating area.



Position the cursor on the desired file in the directory tree.



Load

Load the program into the CNC memory.

Unload

Save the program to hard disk.



Please note:

When you activate "Load", the program is automatically deleted from the hard disk. When you activate "Unload", the program is automatically cleared from the CNC memory.


5. Manage data

5.1 Transfer data (MMC 100.2)	5-56
5.2 Transfer data (MMC 103)	5-59
5.3 Create new file/directory (MMC 103)	5-61
5.4 Load/unload program (MMC 103)	5-62
5.5 Copy/paste, delete (MMC 103)	5-63
5.6 Directory/file/archive properties (MMC 103)	5-64

5.1 Transfer data (MMC 100.2)




MMC 100.2



Services

Select "Services" operating area.



Data out

Read out data:

Select "Data out" menu.

V.24-user

Select interface:

- V.24 user

V.24-printer

- V.24 printer

V.24-PG/PC

- V.24-PG/PC



Position the cursor on the desired file in the directory tree.



Start

Start "Data out".


Stop

Interrupt "Data out".

5.1 Transfer data (MMC 100.2)



MMC
100.2



Data in

V.24
user

V.24-
PG/PC

Read in data:

Select " Data in" menu.

Select interface:

- V.24 user
- V.24-PG/PC




Position the cursor on the desired file in the directory tree.

5.1 Transfer data (MMC 100.2)



MMC
100.2




<input type="button" value="Start"/>	Organize data according to the existing path:
<input checked="" type="checkbox"/>	Path/workpiece from archive file
	Store all files in the directory, irrespective of archived path:
<input type="checkbox"/>	Path/workpiece from archive file
	Store all files in the Clipboard, irrespective of archived path:
<input checked="" type="checkbox"/>	Read into the Clipboard
<input type="button" value="OK"/>	Start "Data in".
<input type="button" value="Stop"/>	Interrupt "Data in".

5.2 Transfer data (MMC 103)



MMC
103



Services


Select "Services"
operating area.




Data out

Read out data:

Select "Programs/data"
menu.



Select data in the directory
tree.



V.24

Select target area:

- V.24 interface

PG

- Programming device

Diskette...

- Diskette drive

Archive...

- "Archive" on hard disk

NC Card

- NC Card

Start transfer:


Start

Initiate data transfer on
disk/archive (softkey label
changes to "Stop").

5.2 Transfer data (MMC 103)



MMC 103



Data in

Read in data:

Select "Programs/data" menu.



Select data in the directory tree.



V.24

Select source area:


- V.24 interface
- Programming device
- Diskette drive
- "Archive" on hard disk
- NC Card

PG

Diskette...

Archive...

NC Card



Start

Start transfer:

Initiate data transfer on disk/archive (softkey label changes to "Stop").




The data transfer is initiated automatically. You can interrupt data transfer at any time by pressing the softkey again.

5.3 Create new file/directory (MMC 103)



MMC 103




Services

Select "Services" operating area.

Manage data

Select "Manage data" menu.



New...

Enter program name and select type of program.



End

By selecting the "End" softkey, you can switch between the areas "Name" and "Type of file".


OK

New file/directory will be created.

5.4 Load/unload program (MMC 103)



MMC
103



Services


Select "Services" operating area.

Manage data

Select "Manage data" menu.



Position the cursor on the desired file in the directory tree.



Load

Load the file from the hard disk into the CNC memory.

Unload

Unload the file from the CNC memory to the hard disk.

5.5 Copy/paste, delete (MMC 103)



MMC
103



Services


Select "Services" operating area.

Manage data

Select "Manage data" menu.



Position the cursor on the source file in the directory tree.



Copy/paste program:

Copy

Select target directory.

Programs data

Close target window.

Paste


Copy source file to target directory.

Clipboard

Copy to or from Clipboard.

Diskette

Copy to or from diskette.



Delete program:


Delete

Delete selected file.

5.6 Directory/file/archive properties (MMC 103)



MMC 103



Services


Select "Services" operating area.

Manage data

Select "Manage data" menu.



Position the cursor on the desired file in the directory tree.



Properties

Select "Properties" menu.



- Rename file
- Convert file type
- Change access rights for file/directory
- Display contents of all files





The access level can only be changed with the appropriate access rights.

6. Automatic Mode

6.1 Select workpiece/program	6-66
6.2 Start/stop/cancel program	6-67
6.3 Repos – Reposition after interruption	6-68
6.4 Overstore	6-70
6.5 Display program level	6-71
6.6 Program correction	6-72
6.7 Execution from V.24 (MMC 100.2)	6-73
6.8 Load/unload program from hard disk (MMC 103)	6-74
6.9 Execution from hard disk (MMC 103)	6-75

6.1 Select workpiece/program




Machine

Select "Machine" operating area.

AUTO

Select "Automatic" mode.



Program overview

Select "Program overview" menu.

Work-pieces

Part programs

Select desired workpiece/part program with the cursor in the workpiece/part program overview.

Selection

Select workpiece/part program.


Change enable

Set (x) or cancel () enable.

6.2 Start/stop/cancel program



MMC 100.2 MMC 103



Machine

Select "Machine" operating area.

AUTO

Select "Automatic" mode.



Please check that:

No alarms are active.
The program is selected.
The feed enable is active.
The spindle enable is active.



Start part program.



Stop part program.




Cancel part program.




A part program which has been interrupted by "NC Stop" can be resumed with "NC Start".

A part program which has been interrupted by "Reset" runs from the start when you press "NC Start".

6.3 Repos – Reposition after interruption



After a program interrupt ("NC Stop") you can move the tool away from the contour in the manual mode. The control saves the coordinates of the interruption point. The traversed path differences of the axes are displayed.



Machine

Select "Machine" operating area.

Jog

Select "Jog" mode.



Reposition after program interruption.



Turning machine:

Traverse axes up to the point of interruption.



Milling machine:

Select axis and





traverse axes up to the interruption point.



Caution:

Travel beyond the interruption point is inhibited. The feed override switches are active.

6.3 Repos – Reposition after interruption



Machine

Select "Machine" operating area.



AUTO

Select "Automatic" mode.



Continue machining.

6.4 Overstore



Machine

Select "Machine" operating area.

AUTO

Select "Automatic" mode.




Overstore with single block:

The program automatically stops at the next block boundary.



Overstore without single block:

Stop part program.





Overstore

Enter the values and functions to be executed.



Run the entered block.

6.5 Display program level




Machine

Select "Machine" operating area.

AUTO

Select "Automatic" mode.



Program level

Display block numbers for main programs and subroutines with the respective pass counts (P).



Current block

Display the blocks of the current program.



Pressing the "Program level" softkey automatically changes the level to and from "current block".

6.6 Program correction



Machine


Select "Machine" operating area.

AUTO

Select "Automatic" mode.



The control has detected a system error in the part program. Execution of the part program is automatically interrupted.



Correct program

Correct the program block with the error.




Continue machining.

6.7 Execution from V.24 (MMC 100.2)



MMC
100.2



Machine

Select "Machine" operating area.

Program overview

Select "Program overview" menu.

Execution from extern.

Select "Execution from external source" menu.



Position the cursor on the desired file in the directory tree.



Start execution from V.24.

Executed blocks appear in the current block window.




Alternatively, it is possible to start execution in the "Services" operating area.

You can change the transfer parameters in the "Services" operating area. The transfer is recorded in the error log.

6.8 Load/unload program from hard disk (MMC 103)



MMC 103



Machine


Select "Machine" operating area.

Program overview

Select "Program overview" menu.



Position the cursor on the desired file in the directory tree.



Load

Load the program into the CNC memory.

Unload

Save the program on the hard disk.




Please note:

When you activate "Load", the program is automatically deleted from the hard disk. When you activate "Unload", the program is automatically cleared from the CNC memory.

6.9 Execution from hard disk (MMC 103)



MMC 103



Machine

Select "Machine" operating area.

Program overview


Select "Program overview" menu.



Position the cursor on the desired file in the directory tree.



Press the "NC Start" key.



Execution fr. hard disk

Start/cancel read-in and execution.





The program remains stored with "Execution from hard disk".

7. Alarms and Messages

7.1 Alarms/messages


7-78

7.1 Alarms/messages



Diagnosis

Select "Diagnosis" operating area.



Alarms

Display alarms:

Display alarms with "alarm number", "date", "explanation" and "cancel criterion".



Delete alarm:



Switch the control off and on again.



Press "Reset".



Press "Acknowledge alarm".





Alarm is canceled with "NC Start".



Alarm is canceled with "Recall".

7.1 Alarms/messages



Messages


Display messages:

Display PLC error messages and PLC operational messages.



Caution:

PLC error messages must always be acknowledged.




Alarm log

Display new

Display alarm log:

Display complete log of alarms and messages which have occurred.

Update alarm log.



Acknowledge MMC alarm

MMC 103:

Select and delete MMC alarm.

SIEMENS AG
A&D MC IS
P.O. Box 3180

D-91050 Erlangen
Federal Republic of Germany

(Fax ++49 9131/98-1145)

From Name	Suggestions Corrections for Publication/Manual SINUMERIK 840D/810D/FM-NC User Documentation
Company/Department Address _____ _____ Telephone: / _____ Telefax: /	Short Guide Operation Order No.: 6FC5298-5AA10-0BP0 Edition: 12.98 Should you come across any printing errors when reading this publication, please notify us on this sheet. Suggestions for improvement are also welcome.

Suggestions and/or corrections