
Section 21: Formats

Overview

From the SETP Command the control has the option to use either FORMAT 1 or FORMAT 2.

Format 1 Format 1 is FADAL style programming and machine operation.

Format 1 has been uniquely designed to have the CNC control reset before restarting machine operation. When the CNC control is in Format 1 the programmer **may** program with the minimal of commands. This helps the user for programming, setup, and operation. Some codes are unique for FORMAT 1 and FORMAT 2. Listed in this chapter are examples for each format's programming style.

Format 2 Format 2 allows a 6M/ 10M /11M style programming and machine operation.

Format 2 follows the design to allow the programmer to completely command the CNC control. All resets therefore must be done by the programmer in the program and machine operation. Some codes are unique for FORMAT 2 and FORMAT 1. Listed in this chapter are examples for each format's programming style.

Format 1 Programming

Notes on Format 1 Style Programming

- 1) Each line requires a sequence number and will be generated by the CNC control. Sequence numbers use an N####.### word. Decimal points can be used to input lines between existing line numbers. The sequence numbers can be added when the program is typed at the computer, but the numbers are added automatically when the program is transferred to the control with the TA (tape input) command. So it is possible to type the program without line numbers and have the control add the line numbers automatically. The NU command is used to renumber the lines.
- 2) Decimals are required for all dimensions, feed rates, and angles.

EXAMPLE: X Y Z ###.#### (or ##.##### for higher precision)
F ####.##
A ####.###
B ####.###

If the decimal point does not appear with dimensions, feed rates, or angles, the control will add them. For example, if an X1 is entered it is accepted as X.0001 (See also DECIMALS and SIGNS).

- 3) The O word on the first line is not required. The O word is used only for identification of the program in the program library for multiple program storage. The first sixteen characters of the comment with the O word will appear when the program library directory is displayed. This comment can be longer than sixteen characters but the remainder of the comment will only appear when the program is listed or printed (See also the section on program library, the PR command).
- 4) If the word NOEDIT is used within the first sixteen characters of the comment on the line with the O word, the program cannot be edited. This is the same function as using the key lock on the pendant. Program can only be deleted with the PR command.

FORMAT 1 Program Example

EXAMPLE 1, without subroutines or subprogram calls with fixture offsets:

```
O# (COMMENT
M6 T1
(TOOL #1 ID
G0 G90 S##### M3 E## X###.#### Y###.####
H# M7 Z###.####
G4 P1000
Math work
M5 M9
G0 G90 80
Z0 G53
M6 T2
(TOOL #2 ID
G0 G90 S##### M3 E## X###.#### Y###.####
H# M7 Z###.####
G4 P1000
Math work
M5 M9
G0 G90 G80
Z0 G53
E0 X0 Y0 H0
M2
```

**FORMAT 1 Program
with Subroutines
and Subprogram
Calls**

*O# (COMMENT
(SUBROUTINE SECTION
L100 (SUB #1 FOR _____ Each sub begins with an L word, a sub
Math worknumber (1-99), and a two digit zero repetition (00)*

M17

L200 (SUB #2 FOR _____) Math work

M17

L300 (SUB #3 FOR _____) Math work

M17 This M17 marks the end of the last sub

*M30 The M30 marks the end of the program's sub section
(MAIN PROGRAM)*

M6 T1(.....TOOL #1 ID

G0 G90 S##### M3 E## X###.#### Y###.####

H# M8 Z###.####

G4 P1000

Math work

L101 This line calls sub #1 one time

M98 P5 L1 This line calls subprogram 5 one time

L215 This line calls sub #2 fifteen times

G91 X###.#### L9 The L9 repeats this line nine times

M5 M9

G0 G90 G80

Z0 G53

M6 T2(.....TOOL #2 ID

G90 G0 S##### M3 E## X###.#### Y###.####

H# M8 Z###.####

G4 P1000

Math work

M5 M9

G0 G90 G80

Z0 G53

E0 X0 Y0

M2

O5 (SUBPROGRAM #5 FOR _____ Math work

M99 Ending this program with an M99 makes it a subprogram

Format 2**Programming****Notes on Format 2
Style Programming**

- 1) The safe block is mandatory at the beginning of the program.

```
O# (COMMENT
(COMMENT
Z0 G53
GO G17 G40 G70 G80 G90 H0 E0 Z0
G28 X0 Y0 Z0   A0 B0 if needed
```

- 2) The G28, with the axis designated to move, will bring the machine to the zero position established by the cold start command (CS) or to the zero position established by the SETX, SETY, SETZ, or SETH commands and/or fixture offsets, whichever was used last. The SET commands can be used to establish a zero position at any desired location. The program does not need to start from the machine home position. See also the section on establishing home position.
- 3) Fixed subroutines such as bolt hole pattern subroutines or pocket cutting routines from other machines cannot be used on this control. See the users manual for information on using fixed subroutines from the CNC 88 control.
- 4) The SETP command allows certain changes to default codes, diameter or radius input, and M7 M8 preferences.
- 5) When typing any variable (R0,R1 - R9) always type the positive or negative symbol before the value, for example, R1+.5 R2+2.34 R3+5.7124 R4-6.765. See *Section Six, Subroutines* for proper usage.
- 6) The H word will only pick up the tool length offset. The D word must be used to pick up the diameter or radius from the tool table.
- 7) Tool changes can be made from any XY position. The M6 code change will move the head to the tool position and make the exchange. The T word and the M6 can appear together, M6T# or T# M6, and usually do with this type of tool changer; however they may appear on separate lines.
- 8) Each line requires a sequence number. Sequence numbers use an N####.### word. Decimal points can be used to input lines between existing line numbers. The sequence numbers can be added when the program is typed at the computer, but the numbers are added automatically when the program is transferred to the control with the TA (tape input) command. So it is possible to type the program without line numbers and have the control add the line numbers automatically. The NU command is used to renumber the lines.

9) Decimals are required for all dimensions, feed rates, and angles.

EXAMPLE: *X Y Z ###.#### (or ##.##### for higher precision)*
F ####.##
A ####.###
B ####.###

If decimal points do not appear with dimensions, feed rates, or angles, the control will add them. For example if an X1 is entered it is accepted as X.0001.

10) The O word on the first line is not required. The O word is used only for identification of the program in the program library for multiple program storage. The first sixteen characters of the comment with the O word will appear when the program library directory is displayed. This comment can be longer than sixteen characters but the remainder of the comment will only appear when the program is listed or printed (see also the section on program library, the PR command).

11) If the word NOEDIT is used within the first sixteen characters of the comment on the line with the O word, the program cannot be edited. This is the same function as using the key lock on the pendant.

12) When transferring a program from another control through the RS232 port, the original line numbers can be maintained by selecting #2 from the N WORDS ORDERED: parameter. Selecting this will cause the control to maintain the original line numbers. The first row is from the original program. When the program is output from the machine, only the original numbers are outputted.

**FORMAT 2 Program
Example**

O# (COMMENT
(COMMENT
G53 Z0
G0 G17 G40 G70 G80 G90 H0 Z0 This safety line is a RESET
E0 X0 Y0 This moves to the SETH position or cold start
G54 X##.#### Y##.#### (or E1 X# Y# or G92 X# Y# are alternative
M6 T1
(TOOL #1 ID
G0 G90 S##### M3 X###.#### Y###.####
H# M8 Z###.#### D#
G4 P1000
Math work
M98 P4 L4 This calls subprogram #4 four times
M98 P3 L27 This calls subprogram #3 twenty seven times
G91 X##.#### G90 L9 The L9 repeats this line nine times

```

M5 M9
G0 G90 H0 Z0
M6 T2
(TOOL #2 ID
G0 G90 S##### M3 X###.#### Y###.#### E## (or G54-G59)
H# M8 Z###.#### D#
G4 P1000
Math work
M5 M9
G0 G90 H0 Z0
E0 X0 Y0 Use this line to cancel all fixture offsets
M30
O3 (SUBPROGRAM #3 FOR _____
Math work

```

M99 Ending this program with an M99 makes it a subprogram. It is called with an M98 P3 L#. The L word is used for number of repeats

```

O4 (SUBPROGRAM #4 FOR _____
Math work

```

M98 P3 L1 Sub #4 is calling sub #3 one time (nesting)

M99 Ending this program with an M99 makes it a subprogram

Default Parameters, SETP Command

FORMAT 1 & FORMAT 2

Changing from FORMAT 1 (FADAL mode), to FORMAT 2 (6M, 10M, 11M mode), is done from the SETP mode.

Format 2 allows a 6M/ 10M /11M style programming and machine operation.

Format 2 follows the design to allow the programmer to completely command the CNC control. All resets therefore must be done by the programmer in the program and machine operation. Some codes are unique for FORMAT 2 and FORMAT 1. Listed in this chapter are examples for each formats programming style.



WARNING: When operating in the FORMAT 2 mode, All RESETS must be commanded by the user.

- 1) The automatic move to home, upon program initiation, must be commanded in the program. Format 2 requires commands to reset. All reset commands must be used with any AUTO command.

- a. In most cases it is required to use the SETCS then the HO command to place the machine to the CS alignment position before typing SETP. Verify that the alignment markers all line up. User may be instructed to COLD START CNC.

The SETP command is generally used by the factory and by the set-up person who installs the machine. It can also be used by the end user to establish programming, baud rate, and output preferences.

Note: The factory set parameters can be found on the inside of the pendant door.

- 1) Move the machine to the cold start position if changes will be made to the parameter settings. The machine Cold Start must be accomplished when parameters are changed.
- 2) From the command mode type SETP then press the ENTER button.
- 3) The menu prompt at the bottom of the screen defines the use of the keyboard to move the cursor to the parameter to change. When the parameter to change has the cursor to its left, the parameter choices will be displayed at the bottom of the screen.
- 4) Select the parameter choice by pressing the number corresponding to the choice and press the ENTER button. The parameter will display the change and the cursor will move to the right.
- 5) Press the MANUAL button to exit and save the parameter setting mode.

Note: If changes are made to any of the parameters, in most cases the CNC control will require a COLD START. Follow the power on procedure (see POWER ON).

The following pages have the recommended format settings for the FADAL FORMAT 1 and FORMAT 2 6MB,10M,11M compatibility.

FORMAT 1 Parameter Settings

The following is the screen's representation upon entering the SETP command. The parameters FORMAT, DEFAULTS, IMM> FIXED CYCLE and CRC MODE

should be set as shown. All other parameters should be set as they are from the factory.

```

                                     PAGE 1 OF
*FORMAT: 1          BAUD RATE: 2400      SPINDLE AFTER M6: N
  AXES: X,Y,Z      TRAVEL: X40 Y20 Z20    PENDANT: MOUNTED
  DEFAULT: G0
  DEFAULT: G90
  DEFAULT: G17      TOOL CHANGER CAP: 21  IMM. FIXED CYCLE: N
  RPM FACTOR: 5    SPINDLE TYPE: 10,000  ORIENTATION FACTR:

THERE ARE TWO PROGRAM OPERATION FORMATS AVAILABLE
DO YOU WANT MAXIMUM 6MB/10M/11M COMPATIBILITY?
* 1) NO, ORIGINAL FADAL STYLE - FORMAT 1
  2) YES, FORMAT 2

P-PAGE ENTER-RT BACKSP-LT U-UP D-DN MAN-EXIT OR SELECT NUM. C

```

Figure 21-1 Format 1 Parameter Settings

```

                                     PAGE 2 OF
*DEFAULT: INCH     M8=FLOOD M7=MIST      3 PHASE > 5% LOW: N
  PU FORMAT: FILE
  CRC MODE: M96    BINARY BUFFERS: 255   HI TORQUE/RIGID: NO
  SPINDLE OFF: NO  TURRET FACTOR: 1      CMD MENU: SPACE
  PALLET: NO       GAIN: 100             RAMP: 100
  ASPECT: 65      TIMERS: OFF            OVERLOAD: 2

ENTER THE DEFAULT VALUE
* 1) INCH
  2) METRIC

P-PAGE ENTER-RT BACKSP-LT U-UP D-DN MAN-EXIT OR SELECT NUM. C

```

Figure 21-2 Format 1 Parameter Settings (Continued)


```

                                     PAGE 3 OF
*SCREW: #2          IPM: 400          XYZ RAMP: 160
Z TAP GAIN: HI     VECTOR: NO        AXIS DISPLAY: LOAD
AUTO BRAKE: YES   A-PALLET: A-AXIS   B-PALLET: B-AXIS

SELECT THE SCREW PITCH TYPE?
  1) INCH PITCH
* 2) 3/10 MILLIMETER PITCH

P-PAGE ENTER-RT BACKSP-LT U-UP D-DN MAN-EXIT OR SELECT NUM. (

```

Figure 21-3 Format 1 Parameter Settings (Continued)

FORMAT 2 Parameter Settings

The following is the screen representation upon entering the SETP command. The parameters FORMAT, DEFAULTS, CRC MODE, N-WORDS ORDERED and TOOL TABLE should be set as shown. All other parameters should be set as they are from the factory.

```

                                     PAGE 1 OF
FORMAT: 2          *BAUD RATE: 2400   SPINDLE AFTER M6: N
AXES: X,Y,Z       TRAVEL: X40 Y20 Z20  PENDANT: MOUNTED
DEFAULT: G1
DEFAULT: G91
DEFAULT: G17      TOOL CHANGER CAP: 21
RPM FACTOR: 5    SPINDLE TYPE: 10,000  ORIENTATION FACTR:

ENTER THE DEFAULT BAUD RATE (THE RATE AFTER POWER-ON)
  1) 110          5) 1200          9) 19200
  2) 150          * 6) 2400        10) 38400
  3) 300          7) 4800
  4) 600          8) 9600

P-PAGE ENTER-RT BACKSP-LT U-UP D-DN MAN-EXIT OR SELECT NUM. (

```

Figure 21-4 Format 2 Parameter Settings

```

                                     PAGE 2 OF
*DEFAULT: INCH          M8=FLOOD  M7=MIST    3 PHASE > 5% LOW: N
PU FORMAT: FILE        N-WORDS ORDERED: YES  TOOL TABLE: DIAMETE
CRC MODE: M96          BINARY BUFFERS: 255   HI TORQUE/RIGID: NO
SPINDLE OFF: NO       TURRET FACTOR: 1       CMD MENU: SPACE
PALLET: NO            GAIN: 100              RAMP: 100
ASPECT: 65           TIMERS: OFF             OVERLOAD: 2

ENTER THE DEFAULT VALUE
* 1) INCH
  2) METRIC

P-PAGE ENTER-RT BACKSP-LT U-UP D-DN MAN-EXIT OR SELECT NUM. (

```

Figure 21-5 Format 2 Parameter Settings (Continued)

```

                                     PAGE 3 OF
*SCREW: #2             IPM: 400             XYZ RAMP: 160
Z TAP GAIN: HI        VECTOR: NO           AXIS DISPLAY: LOAD
AUTO BRAKE: YES      A-PALLET: A-AXIS     B-PALLET: B-AXIS

SELECT THE SCREW PITCH TYPE?
  1) INCH PITCH
* 2) 3/10 MILLIMETER PITCH

P-PAGE ENTER-RT BACKSP-LT U-UP D-DN MAN-EXIT OR SELECT NUM. (

```

Figure 21-6 Format 2 Parameter Settings (Continued)

FORMAT THERE ARE TWO PROGRAM OPERATION FORMATS AVAILABLE

DO YOU WANT MAXIMUM 6MB/10M/11M CAPABILITY?

1) NO, ORIGINAL FADAL STYLE - FORMAT 1

2) YES, FORMAT 2

This parameter allows the user to select 6MB/10M/11M compatibility. The operational difference between the two formats depends upon the coding used.

AXES: X,Y,Z ENTER THE AXIS CONFIGURATION

- 1) *A*
- 2) *A, B*
- 3) *X,Y,Z*
- 4) *X,Y,Z,A*
- 5) *X,Y,Z,A,B*
- 6) *X,Y,Z,B*
- 7) *C only*

When selecting the A or B axes, the machine should be powered off. When the power is returned the axes will be active. COLD START must then be performed.

DEFAULT: G0 ENTER THE DEFAULT VALUE

- 1) *G0*
- 2) *G1*

The code selected is active at power on and when entering the MDI mode.

DEFAULT: G90 ENTER THE DEFAULT VALUE

- 1) *G90*
- 2) *G91*

The code selected is active at power on and when entering the MDI mode.

DEFAULT: G17 ENTER THE DEFAULT VALUE

- 1) *G17*
- 2) *G18*
- 3) *G19*

This parameter is used to select the default machine plane.

RPM FACTOR ENTER THE SPINDLE RPM ADJUSTMENT FACTOR

THE FACTOR MUST BE BETWEEN 0 AND 31

This parameter should only be adjusted by trained maintenance personnel.

BAUD RATE ENTER DEFAULT BAUD RATE (THE RATE AFTER POWER-ON)

- | | | |
|--------|---------|------------|
| 1) 110 | 5) 1200 | 9) 19200 |
| 2) 150 | 6) 2400 | 10) 38400 |
| 3) 300 | 7) 4800 | 11) 57600 |
| 4) 600 | 8) 9600 | 12) 115200 |

The operator may select the desired communications baud rate.

TRAVEL ENTER X,Y,Z TRAVEL

- | | | |
|------------------|-----------------|-----------------|
| 1) X22 Y16 Z20 | 8) X40 Y20 Z28 | 15) X50 Y20 Z20 |
| 2) X20 Y12 Z20 | 9) X60 Y30 Z30 | 16) X50 Y20 Z28 |
| 3) X20 Y13.5 Z20 | 10) X22 Y16 Z28 | 17) X80 Y30 Z30 |
| 4) X22 Y13.5 Z20 | 11) X20 Y16 Z20 | 18) X30 Y20 Z24 |
| 5) X22 Y13 Z20 | 12) X20 Y16 Z28 | 19) X30 Y20 Z32 |
| 6) X20 Y13 Z20 | 13) X30 Y16 Z20 | 20) X20 Y20 Z24 |
| 7) X40 Y20 Z20 | 14) X30 Y16 Z28 | 21) X20 Y20 Z32 |

The machine travel is selected with this parameter.

A-AXIS RATIO ENTER A-AXIS RATIO

- 1) 90:1
- 2) 180:1
- 3) 360:1
- 4) 120:1
- 5) 72:1
- 6) COOLANT
- 7) 60:1
- 8) 144:1

Select the appropriate option for the rotary table being used. See servo coolant option.

B-AXIS RATIO ENTER B-AXIS RATIO

- 1) 90:1
- 2) 180:1
- 3) 360:1
- 4) 120:1
- 5) 72:1
- 6) COOLANT
- 7) 60:1
- 8) 144:1

Select the appropriate option for the rotary table being used. See servo coolant option.

TOOL CHANGER CAP ENTER THE TOOL CHANGER CAPACITY

- 1) 16 TOOL ATC
- 2) 21 TOOL ATC
- 3) 30 TOOL ATC

Select the appropriate tool changer capacity.

SPINDLE TYPE ENTER THE SPINDLE DRIVE TYPE & RPM

- 1) 10,000 HI/LOW
- 2) 10,000 3 STEP
- 3) 15,000 DIRECT
- 4) 5,000 HI/LOW
- 5) 6,500 HI/LOW
- 6) 3750 WYE/DEL.
- 7) 7500 WYE/DEL.
- 8) 5000 DIRECT
- 9) 15K WYE/DEL.

Select the correct spindle type for the machine. This parameter is set at the factory.

SPINDLE AFTER M6 SHOULD SPINDLE COME ON AUTOMATICALLY AFTER A TOOL CHANGE WHEN THE M6 HAD TO TURN THE SPINDLE OFF?

- 1) NO (FADAL RECOMMENDS THIS RESPONSE)
- 2) YES

IF YES, ALL PERSONNEL MUST BE AWARE OF THE POSSIBILITY OF OVER SPEEDING A TOOL BEFORE THE NEW S-WORD IS ENCOUNTERED

When this parameter is selected as YES, the spindle automatically turns on after the tool change. The spindle comes on at the last programmed spindle speed. This may cause an overspeed of the next tool. **It is recommended that this parameter is set to number 1.**

PENDANT ENTER THE PENDANT STYLE

- 1) *KEYBOARD BESIDE THE VIDEO TUBE*
- 2) *KEYBOARD BELOW THE VIDEO TUBE*
- 3) *SAME AS 2 BUT MOUNTED ON FULL-ENCLOSURE CHIP GUARDS*

Select the appropriate pendant location for the machine. When option two is selected the table may make a Y axis positive move before a tool change. This occurs only when the Y axis is five inches or more, in the negative direction, from the cold start position.

M60/A-AXIS BRAKE DOES M60 TURN ON THE A-AXIS BRAKE?

- 1) *YES*
- 2) *NO*

Select the option desired to activate or de-activate the air brake for the axis.

M62/B-AXIS BRAKE DOES M62 TURN ON THE B-AXIS BRAKE?

- 1) *YES*
- 2) *NO*

Select the option desired to activate or de-activate the air brake for the axis.

IMM. FIXED CYCLE SHOULD A FIXED CYCLE EXECUTE IMMEDIATELY?

- 1) *YES*
- 2) *NO, ONLY IF X OR Y DIMENSION WORDS ARE IN THE DEFINITION LINE*

A YES response causes a fixed cycle to be executed immediately upon definition at the current axis location. A NO response requires axis motion to activate the fixed cycle.

ORIENTATION FACTOR ENTER THE SPINDLE RPM ADJUSTMENT FACTOR

THE FACTOR MUST BE BETWEEN 0 AND 31

This parameter should only be adjusted by trained maintenance personnel.

DEFAULT: INCH ENTER THE DEFAULT VALUE

- 1) *INCH*
- 2) *METRIC*

The operator must select the inch or metric mode for the machine. The G70, G71, G20, and G21 check this setting to verify the operational mode.

PU FORMAT SELECT PUNCH OUTPUT FORMAT

- 1) *PUNCHED TAPE FORMAT (TELETYPE STYLE)*
- 2) *COMPUTER FILE FORMAT (NO NULLS)*

This parameter is set to file for computer use. The punch tape format is used when a tape reader is employed.

CRC MODE ENTER THE DEFAULT OUTSIDE CORNER MOVEMENT

- 1) *M96 - ROLL*
- 2) *M97 - INTERSECTIONAL*

This parameter selects the default mode for intersectional cutter radius compensation.

SPINDLE OFF DO YOU WANT THE SPINDLE TO TURN OFF WHEN EXITING JOG OR MANUAL DATA INPUT?

- 1) *NO*
- 2) *YES*

This parameter is set at the factory and should not be changed.

PALLET DO YOU HAVE A PALLET CHANGER?

1) *NO*

2) *YES*

Select the option appropriate for the machine.

ASPECT ENTER THE ASPECT RATIO OF Y TO X

THE RATIO MUST BE BETWEEN 25 AND 150

M7-FLOOD M8-MIST ENTER M7, M8 PREFERENCE

1) *M7 IS FLOOD COOLANT, M8 IS MIST*

2) *M8 IS FLOOD COOLANT, M7 IS MIST*

The operator may select either M7 or M8 as the flood coolant code.

BINARY BUFFERS: SELECT THE NUMBER OF BINARY BUFFERS FOR CNC LOOK-AHEAD.

255

1) 15 3) 50 5) 255

2) 30 4) 100

The BINARY BUFFERS parameter can be changed to increase or decrease the control look ahead. The factory sets the buffers at 255. This is the most effective for programs with many small moves that must be executed rapidly. This parameter is used to more efficiently utilize the Run Time Menu. The smaller the buffers the more quickly the Run Time Menu changes will take effect in the program.

TURRET FACTOR ENTER THE ENGAGEMENT FACTOR FOR THE TOOL TURRET GENEVA GEAR

THE FACTOR MUST BE BETWEEN 1 AND 50 (1 FOR SERVO TURRET)

This parameter is set at the factory. For VMCs equipped with the Servo Turret, this factor MUST always be 1.

GAIN ENTER THE GAIN FACTOR FOR RIGID TAPPING

THE FACTOR MUST BE BETWEEN 0 AND 255

This parameter effects the spindle response during rigid tapping. The higher the number the faster the spindle turns in relation to the feed rate. When the speed is too fast the thread may be too loose.

TIMERS SELECT THE AUTOMATIC TOOL TIMER MODE?

- 1) *ALL TOOL TIMING OFF*
- 2) *DO NOT CHECK*
- 3) *END OF TOOL (AT M6)*
- 4) *AFTER EACH MOVE*
- 5) *AT END OF PROGRAM*

Select the desired option and set a value in the DTT table for TIME. The USED value will be inserted by the control. See DTT command.

**3 PHASE 5% LOW:
NO** IS YOUR 3 PHASE POWER MORE THAN 5% LOW?

- 1) *YES*
- 2) *NO*

The selection chosen is based upon the building power supply.

HIGH TORQUE DO YOU HAVE THE HIGH TORQUE OPTION OR RIGID TAP OPTION?

- 1) *NO*
- 2) *YES*

This parameter is set at the factory.

CMD MENU TURN COMMAND MENUS:

- 1) *OFF*
- 2) *ON*
- 3) *TOGGLE ON WITH SPACE BAR*

The operator may select the command menu structure.

RAMP ENTER THE RAMP FACTOR FOR RIGID TAPPING

THE FACTOR MUST BE BETWEEN 0 AND 255

This parameter sets the speed at which the spindle accelerates during rigid tapping.

Note: Only a factory trained representative should modify this parameter.

- OVERLOAD** ENTER THE MOTOR OVERLOAD FACTOR (2 IS STANDARD)
THE FACTOR MUST BE BETWEEN 1 AND 8
- SCREW** SELECT THE SCREW PITCH TYPE?
1) INCH PITCH
2) 8/10MILLIMETER PITCH
- IPM** SELECT THE MAX RAPID FEED RATE?
1) 400 IPM 4) 800 IPM
2) 500 IPM 5) 900 IPM
3) 700 IPM
- XYZ RAMP** ENTER THE X, Y, & Z RAMP LENGTH FACTOR (160 IS STANDARD)
THE FACTOR MUST BE BETWEEN 50 AND 200
This parameter sets the speed at which the axes accelerate and decelerate during travel.
- Z TAP GAIN** SELECT THE Z GAIN DURING RIGID TAPPING?
1) NORMAL
2) MEDIUM
3) HIGH
Only a factory trained representative should modify this parameter.
- VECTOR** DO YOU HAVE VECTOR DRIVE (10 RPM MIN)?
1) YES
2) NO
- AXIS DISPLAY** DISPLAY THE AXIS FOLLOW ERROR OR LOAD?
1) LOAD PERCENTAGE
2) FOLLOWING ERROR
This option is used to select what the axis display will show on the position display while auto running a program.

A-PALLET WHICH ROTARY AXIS IS INSTALLED ON THIS PALLET?

- 1) *NOT APPLICABLE*
- 2) *A-AXIS*
- 3) *B-AXIS*
- 4) *A-AXIS & B-AXIS*

Select the appropriate option for the rotary axis being used.

B-PALLET WHICH ROTARY AXIS IS INSTALLED ON THIS PALLET?

- 1) *NOT APPLICABLE*
- 2) *A-AXIS*
- 3) *B-AXIS*
- 4) *A-AXIS & B-AXIS*

Select the appropriate option for the rotary axis being used.

AUTO BRAKE AUTOMATICALLY APPLY THE A OR B BRAKE DURING IDLE TIME?

- 1) *YES*
- 2) *NO*

Select the option desired to activate or de-activate the air brake for the axes.

5th AXIS PROGRAMMABLE HEAD DO YOU HAVE THE 5TH AXIS PROGRAMMABLE HEAD ATTACHMENT?

- 1) *NO*
- 2) *YES*

Answer YES if a 4th or 5th axis rotary head attachment is installed in the spindle.

GO DETAIL ENTER THE DETAIL DESIRED FOR GO MOVES

BETWEEN 2 TO 250 TENTHS (251=OFF)

Enter a value between 2 and 250 to set the maximum distance to allow before the control will continue with the next motion block. Smaller values may have the tendency to cause the machine to wait at the end of G0/G5 moves. The value of 251 can be set to turn off the feature. This parameter should be set to any preference, as it will not affect contouring motion.

**AIR VALVE
FEEDBACK**

DO YOU HAVE AIR VALVE FEEDBACK?

- 1) *NO*
- 2) *YES*

Answer NO only for machines built previous to having feedback on the drawbar.

Parameters

Applicable to

FORMAT 2 Only

N-WORDS ORDERED

ENTER THE N-WORD SEQUENCE CONFIGURATION

- 1) *THE N-WORDS ARE IN ASCENDING NUMERICAL ORDER OR THE PROGRAM WILL BE RENUMBERED AFTER INPUT.*
- 2) *THE N-WORDS ARE NOT IN ORDER.*

The CNC 88 requires each block of NC code to have sequence numbers in numerical order. Since the 6MB/10M/11M controls do not require block numbers in numerical order, select option number 2. Upon tape input the CNC will add sequence numbers for reference. Otherwise after tape input the program must be renumbered if the sequence numbers are not in numerical order.

TOOL TABLE

WILL THE TOOL COMPENSATION TABLE HAVE THE RADIUS OR DIAMETER?

- 1) *DIAMETER*
- 2) *RADIUS*

The cutter offset specification in the tool compensation table may be defined as a diameter or radius.

The SETP mode is exited by pressing the MANUAL key. If new values were selected, the CNC may require that you perform the Cold Start procedure (see CS command).